




# REFINISH



## PROCESS CHART



### AFTER SANDING WITH P1200 AND UPWARDS

### DEEP AND LIGHT SCRATCHES

### HOLOGRAMS / ONE STEP POLISH


### HIGH GLOSS

**STEP 1**  
REFL30

RF2310  RF2316 






**STEP 1**  
REFL30

RF2310  RF2316 

OR

**STEP 1**  
REFL40

RF2410  




**STEP 1**  
REFL90

RF2156 



**STEP 1**  
REFL12

RF2170 



**STEP 2**  
REFL90

RF2156 



**STEP 2**  
REFL90

RF2156 



**STEP 2**  
REFLWC  
RF2211C



**STEP 2**  
REFLWC  
RF2211C



**STEP 3**  
REFLWC  
RF2211C





**STEP 3**  
REFLWC  
RF2211C



**PANEL SPRAY**  
Surface Control And Preparation

Panel Spray can be used after each step to identify imperfections and remove any polish residue.



 Rotary  
 Dual Action

### PROCESSING

**1:** Wash the car according to the washing process.



**2:** Evaluate the paint and choose the appropriate option from those shown above. Then, apply a moderate amount of polishing compound onto the polishing pad. Avoid excessive usage.

**3:** Spread the polish carefully using the polisher at the lowest setting, then gradually increase the speed to the recommended RPM. Always keep the machine in motion to prevent overheating and potential damage to the paint.


**4:** Gently buff the polished surface with the recommended Cartec Microfiber Cloth.



# REFINISH



## PROCESKAART



### NA HET SCHUREN MET P1200 EN HOGER

### DIEPE EN LICHTE KRASSEN

### HOLOGRAMMEN / POLIJSTEN IN ÉÉN STAP

### HOOGGLANS



**STAP 1**  
REFL30

RF2310  
RF2316



**STAP 1**  
REFL30

RF2310  
RF2316



OF



**STAP 1**  
REFL40

RF2410



**STAP 1**  
REFL90

RF2156



**STAP 1**  
REFL12

RF2170



**STAP 2**  
REFL90

RF2156



**STAP 2**  
REFL90

RF2156



**STAP 2**  
REFLWC  
RF2211C



**STAP 2**  
REFLWC  
RF2211C



**STAP 3**  
REFLWC  
RF2211C



**STAP 3**  
REFLWC  
RF2211C



### PANEL SPRAY

Surface Control And Preparation

Panel Spray kan na elke stap worden gebruikt om imperfecties vast te stellen en polijstresten te verwijderen.

Roterend  
 Dual Action

## VERWERKEN

**1:** Was de auto volgens het wasproces.



**2:** Beoordeel de lak en kies de juiste optie uit de bovenstaande opties. Breng een gematigde hoeveelheid polijstpasta aan op de polijstpad. Vermijd overmatig gebruik.

**3:** Verdeel het polijstmiddel met de polijstmachine op de laagste stand en verhoog vervolgens de snelheid tot het aanbevolen toerental. Houd de machine altijd in beweging om oververhitting en mogelijke schade aan de lak te voorkomen.

**4:** Poets het gepolijste oppervlak voorzichtig schoon met de aanbevolen Cartec Microvezeldoek.