## **TECHNICAL DATASHEET**

# **TAR & GLUE REMOVER**

Article code: 1227





### Description:

Tar & Glue Remover effectively and quickly removes tar and aspHalt residue.

#### **Benefits:**

- Cleans fast and thoroughly
- To be used during pre-wash
- Ideal product for dry finishing

#### **Application:**

Vehicles but also anything contaminated with tar, bitumen or aspHalt can be cleaned with this product.

#### Directions for use:

Always use Tar & Glue Remover in a well-ventilated area. Spray the product undiluted on the contaminated parts with a pressure pump or nebulizer. Allow the product to take effect for approximately 1-3 minutes depending on the pollution and outside temperature. Prevent the product from drying out. Use a soft cloth to remove the dissolved dirt. Rinse with water if necessary. Always test the product on an inconspicuous place before use to avoid possible damage. Keep the product away from lenses and hard plastics, as these can eventually react and crack.

#### Tips & tricks:

Make sure there is no water film on the lacquer before applying the Tar and Glue remover. This impedes the operation of the product. Tar and Glue remover also works very well to remove window sealant and sticker residue.

#### **Related products:**







